

User Manual Version 2.15



HAND HELD BRAKE METER





Licence ID number:





DECLARATION OF CONFORMITY

We, AutoTest products Pty Ltd. declare under our sole responsibility that the product AutoStop Mini Plus is in conformity with the provisions of the following Council Directive: 1999/5/EC.

A copy of the Declaration of Conformity is available from http://www.autotest.net.au

© AutoTest Products Pty Ltd (AutoTest) [2022].

Copyright in the drawings, information and data recorded in this document (the information) is the property of AutoTest Products. This document and the information are solely for the use of the authorised recipient and this document may not be used, copied, or reproduced in whole or part for any purpose other than that for which it was supplied by Auto Test Products. Auto Test Products makes no representation, undertakes no duty, and accepts no responsibility to any third party who may use or rely upon this document or the information.

Under no circumstances shall Auto Test Products be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability of

contents of this document. Auto Test Products reserves the right to revise this document or withdraw it at any time without prior notice.

Please dispose of batteries properly.

Table of Contents AutoStop® Mini Plus

UNPACKING AND FIRST TIME USE	
Unit activation	
2 Self Test and Battery Check	
FOR YOUR SAFETY	
OPERATION	4
Test Conditions and Test Area	4
2 Set-Up in Vehicle	4
3 Changing the units	4
Running the Test	5
5 Test Instructions Summary	6
Other Functions	6
Printing on Bluetooth printer (optional a	ccessory)7
3 Menu Reference	8
DOWNLOADING	
Systems Requirements	
2 Installing the Data Logger Software From	n CD12
Installing the Data Logger Software From	n Internet12
Downloading Tests using the Data Logg	er Software12
4.1 Downloading via USB	13
4.2 Downloading via Bluetooth	21
5 Using the Data Logger software	
SPECIFICATION	
Hardware Specifications	
2 Features	
CALIBRATION PROCEDURE	
Return of AutoStop Mini Plus for Calibra	ition29
1.1 Packaging	
.1.2 Shipping	
1.3 Documentation	
TROUBLESHOOTING	
WARRANTY	
AUTHORISED SERVICE AGENTS:	
1 2 1 2 3 4 5 5 7 3 1 2 3 4 4 5 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	UNPACKING AND FIRST TIME USE Unit activation

1 UNPACKING AND FIRST TIME USE

Congratulations on your choice of an AutoStop Mini Plus. Please take the time to read this User's Manual before using the AutoStop Mini Plus in the field. Incorrect or inappropriate use of this instrument may void the warranty. Retain the packing materials for future shipping and transport of the unit for calibration every two years.

Please complete the warranty registration card and post it to AutoTest Products Pty Ltd, alternatively visit our website www.autotest.net.au and complete your warranty registration on line. Your warranty registration ensures that you are kept up-to-date on any software or hardware changes to your AutoStop Mini Plus.

The packing box of your AutoStop Mini Plus should contain the following:

- 1. AutoStop Mini Plus
- 2. User Manual
- 3. Warranty Registration Card
- 4. Calibration Certificate
- 5. Power Adaptor

Optional Accessories:

- MiniPlus Data logger software CD-ROM
- Data Download USB cable
- Bluetooth Wireless printer
- Rare Earth magnet motorbike kit

AutoStop Mini Plus determines triaxial deceleration, measuring forward as well as sideways deceleration (lane change). AutoStop Mini Plus has a twelve-button operation via a tactile membrane keypad with LCD display. It is lightweight (500grms) and compact (200x70x40mm) and can be installed anywhere in the vehicle.

1.1 Unit activation

When you receive your new Meter, you must activate it before you can use it. When you turn it on for the first time, you will come to the main menu. The first option on the menu will be "**Activate**".

Press the ENTER key to begin activation. You are now prompted to enter the 5-digit serial number, one digit at a time. Press ENTER to confirm, DEL to re-enter.

Once your meter is activated, it is ready for use, and you will never need to perform the activation again.

1.2 Self Test and Battery Check

The self-test function is activated each time the AUTOSTOP[™] Mini Plus is powered, it checks the clock, the battery level and the calibration due date. The sequence as follows: - after initial power up and start-up splash screen sequence the display will indicate "**Test?**" If the battery does not have sufficient charge to be used, then it will display "Warning: Battery Low".

2 FOR YOUR SAFETY

Read these simple guidelines. Not following them may be dangerous. Read the complete user guide. Further detailed information is given in this manual.

SWITCH ON SAFELY

Do not switch the device on when wireless device use is prohibited or when it may cause interference or danger.



INTERFERENCE

All wireless devices may be susceptible to interference, which could affect performance.



SWITCH OFF WHEN REFUELING

Do not use the device at a refuelling point. Do not use near fuel or chemicals.



SWITCH OFF NEAR BLASTING

Follow any restrictions. Do not use the device where blasting is in progress.



USE SENSIBLY

Use only in the positions as explained in the product documentation.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



ACCESSORIES AND BATTERIES

Use only approved accessories and batteries. Do not connect incompatible products.



WATER-RESISTANCE

Your device is not water-resistant. Keep it dry.



CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

3 OPERATION

3.1 Test Conditions and Test Area

The vehicle must be stationary (at a complete stop) prior to commencement of the test. Ideal conditions are to test the vehicle at a location where no other or only few vehicles are present. However, if it is necessary to use another area, such as a public road, only commence the test if there is no danger of an accident. The test area should be a sealed, flat bitumen road. The headwind should be less than 15km/h.

Test starts with first movement of the vehicle, and concludes when the vehicle comes to a complete stop. The forward direction of the vehicle is determined when the vehicle first starts to move. For example, if the test is started when the vehicle pulls out from the kerb, then the calculated forward direction will be at an angle to the true forward direction. The first movement of the vehicle must be in the forward direction. Please be sure to follow the brake test procedure detailed in the latest version of the relevant Inspection Manual when carrying out a statutory test.

3.2 Set-Up in Vehicle

Attach the Mini Plus to the dashboard, front passenger seat, foot well or centre console so that the screen is clearly visible and the buttons are accessible. AutoStop Mini Plus is self-aligning by identifying its orientation during acceleration at the beginning of each test - Mini Plus can be installed at any angle facing any orientation, but must be secure for the entire duration of the test as movement can cause wrong deceleration readings.

Note: If Mini Plus is configured for use in heavy vehicles, it should only be mounted flat on a levelled surface, or on the side-window of the vehicle using suction cup mounts. In such cases, if the tilt angle of the device is outside the tolerance level, the device will display "Slope too large". The tilt warning message will disappear automatically once the slope angle of the unit is adjusted to the level plane (in reference to ground).

3.3 Changing the units

The resultant average deceleration and max deceleration can be viewed in different units like g, m/s^2 or %. The speed, stopping distance and the side shift can be viewed can be in imperial and metric units. To select the units, press ON/OFF button to power up the unit. The display will show "**Test?**" press \rightarrow until it displays "**Set Accel. Unit?**" to change the units of average and maximum deceleration. There are three options for acceleration units: m/s^2 , g or %. Press \rightarrow to select a unit and ENTER to set a unit.

Acceleration Units		
m/s ²		
g		
% (where 0% = 0.00g, 100% = 1.00g)		

The units of speed, stopping distance and side shift can be changed to imperial or metric. Select **Imperial/Metric?** option from the main menu. Press ENTER. Select imperial or metric units and press ENTER. The speed, stopping distance and side shift in both units are as follows:

Unit	Imperial	Metric
Speed	Miles per hour (mph)	Kilometres per hour (km/h)
Stopping distance	Feet (ft)	Meter (m)

3.4 Running the Test

Turn on AutoStop Mini Plus by pressing ON/OFF. The Mini Plus will go through a start-up procedure and show the calibration due date. The display will show "**Test**?" press 'ENTER'. The Mini Plus will initialise the test procedure by prompting the user to enter "**Examiner ID**", "**Customer Name**" and "**Vehicle Registration No**." The Mini Plus will remember the previously stored Examiner ID. To change the Examiner ID, press \rightarrow then key-in the new ID. Once the vehicle registration number has been entered, the Mini Plus will then prompt the user select the vehicle category. The vehicle category can either be "Light Vehicle" (VEHICULE LEGER) or "Heavy Vehicle" (VEHICULE LOURD). Once the vehicle type. The vehicle-type is selected from the following tables depending on the previously selected vehicle category.

Vehicle types for Light Vehicles (VEHICULE LEGER)

Туре	Limit value (m/s²)
VP > 01/10/1989	5.0
VUL > 01/10/1989	5.0
1956 < VP < 1989	5.0
1956 <vul 1989<="" <="" td=""><td>4.5</td></vul>	4.5
VP < 31/12/1955	3.5
VUL < 31/12/1955	3.0

Vehicle types for Heavy Vehicles (VEHICULE LOURD)

Туре	Limit value (m/s²)
M1 >3,5t	5.0
M2,M3 avec ABR	5.0
M2,M3 sans ABR	4.8
N1 > 29/09/1989	5.0
N1 < 30/09/1989	4.5
N2,N3 > 01/01/12	5.0
1989 <n2,n3< 2012<="" td=""><td>4.5</td></n2,n3<>	4.5
N2,N3 < 30/09/89	4.3
Ensemble routier	4.3

Press the (\rightarrow) and DEL keys to scroll through the list of vehicle types. When a particular vehicle type is displayed on the screen, press the ENTER key to select it and continue to the next step. The Mini Plus will then show "**Press any key to commence the test**". After pressing any key, the display will show "**Ready to go**". Drive the vehicle to the desired test speed and apply the brakes. When the vehicle has come to a halt the Mini Plus will finish the calculations and will display the results – you can then simply compare them with the specific brake values according to your local regulations. The results that will be displayed are:

- 1. Average Deceleration
- 2. Maximum Deceleration
- 3. Test Duration

3.5 Test Instructions Summary

Screen Display	Instruction	Keys to Press
Blank Screen	Switch On	ON/OFF
Initial splash screen		Press any key to skip
Test?	Start to run test	ENTER
Examiner?	Enter Examiner ID if it is not	Press → key and key-in ID
	stored previously	and press ENTER
Customer:	Enter customer name	Key-in customer name and press ENTER
Reg No:	Enter the Registration no	Key-in registration no and press ENTER
Test with GPS?	Conduct test with GPS	Press ENTER for YES and any other key for NO
Press any key to	Press any key to commence	Press any key to commence
commence the test	the test	the test
Ready to go…	Accelerate the vehicle	
Prelude	Forward direction detected.	
	Keep accelerating to	
	desired speed, then brake	
Sampling	Wait for result	
Calculating	Wait for result	
Save?	To save test result	Press ENTER to save or \rightarrow
		to go to next item
Print?	To print test result on	Press ENTER to print or \rightarrow
	remote Bluetooth printer	to go to next item
Print Another?	To print duplicate test result	Press ENTER if you want to
		print the test result or press
		\rightarrow
Repeat Test?	To repeat same test	Press ENTER to repeat the
-	-	test or \rightarrow to go to main
		menu.

Must:

- Fix Mini Plus securely
- Install in a stationary vehicle
- Must drive in a straight line

Must not:

- Turn car after starting test
- Hold unit in hand or on body
- Move Mini Plus after pressing start
- Skid wheels

"A good stop is like stopping at a traffic light – steady."

3.6 Other Functions

- View Results? : Press ENTER and display will show the test number and the date and time of test. Press → to select the required test number and press ENTER to view each test result. Mini Plus can store up to ninety test results. At the end there is a "Clear Results?" option to clear all test results. The Mini Plus will hold ninety tests and will display "Memory full" when the memory is full and stored data has to be cleared.
- Adjust Contrast? : Press ENTER to adjust the contrast of the display and press → to increase the contrast and DEL to reduce contrast.
- Set acceleration units? : Press ENTER to select acceleration unit. The acceleration units can be changed to g, percentage or m/s²
- Imperial/Metric? : Press ENTER to change to Imperial or Metric units.
- **View Clock? :** This function is for viewing the date and time set on Mini Plus. Press ENTER to view the clock
- **Battery Life?** : Press ENTER to view the battery life of the Mini Plus
- View Accel? : This function is to view the X, Y and Z-axes of the accelerometer. Press ENTER to view these values.
- **View Test Count? :** This function is to view the total number of tests carried on the Mini Plus after calibration. Press ENTER to view the test count.
- Language? : This function allows users to select a different interface language. Press ENTER to view available languages. Note: results obtained using French language will be based on SRV-P036 standard.

3.7 Printing on Bluetooth printer (optional accessory)

In order to print the test results on Bluetooth printer, switch on the printer and give print command from the Mini Plus. Mini Plus will display "Finding printer" while searching for the Bluetooth printer. Once the Bluetooth printer is found, Mini Plus will automatically issue the printout of the test via the Bluetooth printer.

Note: When Mini Plus is not able to find a Bluetooth printer it will display "*No printer found*" and "*Find printer*? Y/N" messages on the LCD screen. Switch OFF the Bluetooth printer and switch it back ON and select "*Find printer*? Y" from Mini Plus to retry printing.

3.8 Menu Reference

Display Main Menu	Display Sub Menu	Description	Keys to Press
Activate Unit?		This to activate the MiniPlus as the unit is locked prior to shipment	Press ENTER or → to view next item on main menu
	Please enter the 5- digit Serial Number code of this unit, then press ENTER to confirm, or DEL to re-enter. Press any key to begin		Press any key to go to next sub- menu
	Code:	This is to enter the 5- digit serial number code	Key-in the 5-digit serial number and Press ENTER
	Unit Activated	This is an indication that the unit has been activated	Press ENTER
Test?		This does not appear if unit is not activated. This is for carrying out the test	Press ENTER
	Examiner?	This is for enter the name of the person carrying out the test.	Press →, when cursor appears key-in the examiner name
	Customer:	This is for entering the name of the customer	Key-in the customer name and Press ENTER
	Reg No:	This is for entering the registration number of the vehicle under test	Key in the registration number and press ENTER
	Test with GPS?	This is to decide whether or not the test require GPS location	Press ENTER for YES and any other key for NO
	Press any key to commence test.	This is an indication to press any key to commence the test	Press any key
	Stabilising	This is when the unit is checking its stability	
	Ready to go	Accelerate the vehicle to the desired speed	
	Prelude	I his indicates forward motion of the test vehicle.	

	Sampling	This indicates that the brakes have been	
		applied and it is	
		sampling data for	
		calculation	
	Calculating	This indicates that the	
	Salouluting	test is complete and	
		the unit is calculating	
		the results	
	Save?	This is for saving the	Press ENTER to
		current test result	save or \rightarrow to go to
			next sub menu
	Print?	This is for printing the	Press ENTER to
		test result via	print or \rightarrow to go to
		Bluetooth printer	next sub menu
		(optional accessory)	
	Print Another?	This option is to print	Press ENTER to
		another copy of the	print or \rightarrow to go to
		same test	next sub menu
	Repeat Test?	This is for repeating	Press ENTER
		test	
View Results?		This is for viewing the	Press ENTER to
		stored data	view results or \rightarrow to
			go to next sub
			menu
	3/n	This is third (last)	Press ENTER to
		result out of <i>n</i> stored	view results of the
		results	second test or
			Press \rightarrow to go to
			next sub menu
	2/n	This is second result	Press ENTER to
		out of <i>h</i> stored results	view results of the
			second test or
			Press \rightarrow to go to
	41	This is first as sult and	
	1/1	I HIS IS TIRST RESULT OUT	Press ENTER TO
			second test or
			Press \rightarrow to go to
	Cloar Booulto?	This is to close the	
	Sieai Resuits?	results stored on Mini	clear stores data or
			μ press \rightarrow to go
	Are you sure? V/N	This is a confirmation	
	Ale you sule? T/N	for clearing the results	$Use \rightarrow lo select$
		stored on Mini Dlus	Yes/No, then
			press ENTER

Set Accel. Unit?		This is to set the units of average and maximum deceleration	Press ENTER to set the acceleration unit or \rightarrow to go to next main menu
	Accel unit: m/s ²	This is to set the units of average and maximum deceleration in terms of 'm/s²'	Press ENTER to set or →to select another unit
	Accel unit: g	This is to set the units of average and maximum deceleration in terms of 'g'	Press ENTER to set or → to select another unit
	Accel unit: %	This is to set the units of average and maximum deceleration in terms of '%'	Press ENTER to set or \rightarrow to select another unit
Imperial/Metric?		This is to change the units of speed, stopping distance and side shift	Press ENTER to set the units or →to go to main menu
	I/M: Metric	This is to change the units of speed, stopping distance and side shift to metric	Press ENTER to set the unit to metric or press → to select another unit
	I/M: Imperial	This is to change the units of speed, stopping distance and side shift to imperial	Press ENTER to set the unit to imperial or press →to select another unit
View Clock?		This is to view the date and time on the Mini Plus	Press ENTER to set the units or →to go to main menu
	Date: dd/mm/yy	This shows the date on the Mini Plus	Wait until display shows time or Press → to view time or Press ENTER to go to main menu
	Time: hh:mm:ss	This shows the time on the Mini Plus Note: press '1' to toggle daylight saving. When daylight saving is enabled, '*' will be displayed on LCD.	Wait until the display shows date or Press → to view date or Press ENTER to go to main menu

Battery Life?		This shows the battery	Press ENTER to
		life on Mini Plus	view battery life or
			press \rightarrow to return
			to main menu
View Accel. ?		This is to view X, Y	Press ENTER to
		and Z-axes of the	view acceleration
		accelerometer	or press \rightarrow to
			return to main
			menu
	vsum :	This shows the vector	Press \rightarrow to view
		sull of all three axes.	another axis or
			to main monu
	¥.	This shows the X-axis	
	Λ.	of the accelerometer	$rress \rightarrow 10 \text{ view}$
			nress ENTER to go
			to main menu
	Y:	This shows the Y-axis	Press \rightarrow to view
		of the accelerometer	another axis or
			press ENTER to go
			to main menu
	Z:	This shows the Z-axis	Press \rightarrow to view
		of the accelerometer	another axis or
			press ENTER to go
	T '14		to main menu
		I his shows the tilt	Press \rightarrow to switch
		meter	to another screen
		meter	of press ENTER to
View Test		This is to view the total	Press ENTER to
Count?		number of tests carried	view the count or
		out on the Mini Plus	\rightarrow to go to main
			menu
Printer Type?		Allows user to	Press ENTER to
		configure printer	open menu
	-	settings	
	Bluetooth: YES	To enable or disable	Press \rightarrow to toggle
		Bluetooth printer	between "YES" and
		Note: If Bluetooth printer	ENTER to save
		is disabled, the printing	settings and return
		will occur via RS232.	30 and 16 and 18
Language?		This allows users to	Press ENTER to
		change the unit	view available
		interface language.	languages

English ?	Changes interface language to English	Press ENTER to select English language or \rightarrow to see the next language
French ?	Changes interface language to French. Note: Results obtained using French language will be based on SRV- P036 standard.	Press ENTER to select French language or → to see the next language

4 DOWNLOADING

The AUTOSTOP[™] Mini Plus can hold 100 tests numbered one to hundred. Test results stored in Mini Plus can be downloaded to a PC using a USB cable, or via Bluetooth interface. To download the tests, a datalogger software needs to installed on the PC. The datalogger software can be installed from the provided CD or can be downloaded from the Internet.

4.1 Systems Requirements

To use the datalogger software, the PC must meet the following requirements:

- **Operating System:** Windows 2000 or later
- **Disk Space:** 10 MB of free hard disk space

4.2 Installing the Data Logger Software From CD

To install the datalogger software from the provided CD, perform the following steps:

- 1. Insert the Mini Plus Data logger Software CD into your disk drive.
- 2. Go to My Computer and select your CD-Rom drive (usually D:\ or E:\)
- 3. Select installation file "*setup.exe*" and run it.
- 4. Follow Setup prompts. Make sure you run the application with administrator level privileges.

4.3 Installing the Data Logger Software From Internet

The latest version of the AUTO*STOP*[™] Mini Plus datalogger software can be freely obtained from the Internet by opening the following URL:

http://autotest.net.au/ (Select 'All products' then select AutoStop Mini Plus)

When the above link opens, select 'Datalogger Software' link under 'Downloads'. Then simply download and run the installation file.

4.4 Downloading Tests using the Data Logger Software

There are a couple of ways of downloading data from Mini Plus. The data can be downloaded via USB or Bluetooth. Once the datalogger software has been installed, run the software and follow the downloading instructions given below.

4.4.1 Downloading via USB

Once the Data Logger software is installed, run the Data Logger software and connect the Brake Meter to the PC via the supplied USB cable.



Once the USB cable is connected to the PC, switch ON the Brake Meter by pressing the ON/OFF key. When the Brake Meter is switched ON, the PC will recognise the Brake Meter device and will search for the USB drivers.

Installing device driver software 🌂 🗙 Click here for status.	Device Attached 🔌 🗙 AutoStop MiniPlus
Device driver software was not success Click here for details.	sfully installed 🌂 🗙

Open device manage to install the USB drivers. The device manager can be accessed by typing 'devmgmt.msc' in the Run Window. The Run Window can be accessed by pressing III + R from the keyboard. Make sure you have administrator level privileges when accessing Device Manager.

📼 Run	
	Type the name of a program, folder, document, or Internet resource, and Windows will open it for you.
Open:	devmgmt.msc 🗸 🗸
	OK Cancel <u>B</u> rowse

Select '*AutoStop MiniPlus*' in the device manager (under *Other devices*) and right click on it. Select "Update driver/software".



Select "Browse my computer for driver software" to specify the location where the drivers are located.

• 1	Update Driver Software - AutoStop Maxi	
Ho	w do you want to search for driver software?	
a	Search automatically for updated driver software Windows will search your computer and the Internet for the latest driver software for your device, unless you've disabled this feature in your device installation settings.	
4	Browse my computer for driver software Locate and install driver software manually.	
		Cancel

When the browse window is shown, select the USB driver folder located in the directory where the AutoStop Mini+ datalogger software is installed. On a 64-bit operating system, the default location where USB drivers are likely to be found is at "*C:\Program Files* (*x86*)*AutoTest\AutoStop Mini+ Data Logger\USB Drivers*". On a 32-bit system, the USB driver's folder would be at "*C:\Program Files\AutoTest\AutoStop Mini+ Data Logger\USB Drivers*".

	Browse For Folder
	Select the folder that contains drivers for your hardware.
	AutoLight Plus Download AutoStop Micro+ Datalogger AutoStop Mini+ Data Logger USB Drivers UZBee Drivers UZBee Plus Drivers AutoStop Suspension Meter Folder: USB Drivers OK Cancel
🕒 🛛 U	Ipdate Driver Software - AutoStop MiniPlus
Bro	wse for driver software on your computer
Searc	ch for driver software in this location:
ram	Files (x86)\AutoTest\AutoStop Mini+ Data Logger\USB Drivers 👻 Browse
∀ In	Let me pick from a list of device drivers on my computer This list will show installed driver software compatible with the device, and all driver software in the same category as the device.
	Next Cancel

If the Windows displays the following warning message, select "Install this driver software anyway".



If Windows prompts the following dialogue box, select "Install" to install drivers.



When Windows has completed installing the drivers for the USB interface, the following window will appear. Notice the COM port number displayed on the titlebar. The COM port will be used when downloading data from the meter using the datalogger software.

🕞 📱 Update Driver Software - AutoStop MiniPlus (COM27)	×
Windows has successfully updated your driver software	
Windows has finished installing the driver software for this device:	
AutoStop MiniPlus	
	Close

Once the USB drivers have been installed, Windows will diplay the following pop-up message each time the brake meter is connected to the PC via USB interface.



To verify the installation of the USB driver, locate "*AutoStop MiniPlus*" in the device manager under "*Ports (COM & LPT)*". If the device drivers are successfully installed, there will be a COM port number written next to the device name. In the following example, the COM port number is "COM27".



To download the results, open AutoStop Mini Plus datalogger software and click on *"Download"* button.

AutoStop Mini+ Dat	a Logger v2.00.0.0					- D X
🕂 Download	P Open	Save As	Export	Print	i Settings	About
					-B*	~
_						
	Download Wi	zard				
	Chan (d), Dia			alle a de		
	Step (1): Pie	ase select com	munication me	ethoa:		
	Rec	uires a Serial C	n Cable			
		Connection				
	Rec	uires a USB Ca	ble	(Mini+v2 or a	above)	
	C Pluz	atooth				
	Rec	uires a Bluetoo	oth interface	(Mini + v2 or a	above)	
	O PF (onnection				
	Rec	uires a UZBee	MACdongle	(Mini+v1 onl	y)	

Select USB connection and then press Next.

Download Wizard
Step (2): Please make sure your Mini+ is turned ON. Connect the device to the PC via the supplied USB cable.
Step (3): Specify the COM port used by the USB interface on your computer:
COM27 V
Cancel Back Next

🖉 Cancel

Back

Next 🗖

Select the COM port of the USB connection. The COM port is the same port obtained earlier during the USB drivers installation process. Make sure the brake meter switched ON and it is connected to the PC via the USB cable. Press Next to continue.

Download Wizard		
Step (4): If the Mini+ is currently switched off, switch it on now. This software will automatically commence download when a connection is detected.		
If you are stuck on this screen for a long time, make sure the Serial Cable is firmly plugged in on both ends, check that you have selected the correct Serial Port, and try switching the Mini+ off and on again.		
Status: Waiting for connection		
Cancel Cancel Next		

Once the connection has been connected successfully, the downloader will display a list of all tests currently stored on the meter.

Test #	Test date	Vehicle reg.	*
V 16	19/11/2014 4:38:24 PM		
▼ 17	20/11/2014 11:21:53	А	
V 18	20/11/2014 11:58:03	AJMWT	
V 19	20/11/2014 1:43:56 PM	WM	
V 20	20/11/2014 2:37:46 PM	AM4	
V 21	20/11/2014 5:36:03 PM		Ξ
V 22	20/11/2014 5:38:22 PM		-
•	III		Þ
V Select Al)		

Select the tests that need to be downloaded and then press Next. Datalogger software will automatically download all selected tests.



Download Wizard	
Download Completed.	
AutoStop Mini+S/N:	00123
Number of tests:	22
Cancel	Back Finish

Once the desired tests have been downloaded, press Finish to return to the main window and view test results.

4.4.2 Downloading via Bluetooth

Before connecting the brake meter to the PC using the Bluetooth interface, make sure the PC supports Bluetooth connectivity.

Once the Data Logger software is installed, run the software on the PC and switch ON the brake meter by pressing the ON/OFF key.



Note: the screenshots provided below many not be the same on your PC. For information regarding Bluetooth device pairing on your PC, please refer to the documentation of your Bluetooth Manager.



Select the device Mini+##### from the list of discovered Bluetooth devices and create pairing.

A ?	Refresh Services	
	Pair Device	
Mini+001	Connect	•
	Disconnect	F
	Save Connection As Shortcut	- F
	Status	
Bluetooth	Properties	2.1

When prompted for the pairing code or pin number, enter "0000".

Enter Blu	ietooth Passkey		×
*	A remote device r relationship for fut passkey on this d Remote Device: Address Passkey: Time Left: 26 s	eeds a Bluetooth Passkey to create Paired ure connections. Please use the same evice and on the remote device: Mini+00123	OK Cancel
		Refresh Services	

Once the pairing is established, refresh device services and connect using Bluetooth serial port service.

Status...

Properties...



If the following message appears, note down the serial port and press Yes. The serial port will be later used by the datalogger software.

Quick Co	nnect		
?	Automatic connection established. Do you want to connect to this device automatically when Windows applications open the serial port?		Yes
	Serial Port:	COM5	INO
	Remote Device:	Mini+00123	
Alw	ays show this dialo	g.	

Users can also check the COM port of the Bluetooth device by viewing the status of the device.

Remote Device Status

		General		
		Connection		
		Device Name:	Mini+00123	
		Status:	Connected.	
		Duration:	00:01:36	
		Paired:	Yes	
		Role:	Slave	
1. 1. 1.		COM Port:	COM5(SPP)	
		Activity — Se	nt	Received
1 (B)	Refresh Services	Bytes: 10	09	129
Mini+0012	Unpair	- Radio Signal Stren	ngth	
	Connect •	 Weak	Good	Strong
	Disconnect •			
	Save Connection As Shortcut			
	Status	Properties	Disconnect	Unpair
	Properties		OK Canc	el Help

Once the Bluetooth connection is setup, the user can now download test results from Mini Plus using the Bluetooth interface. To download the results, open AutoStop Mini Plus datalogger software and click on "Download" button.

i Settings	About
	Settings

When the following connection window appears, select "Bluetooth" connection and press Next.

Download Wizard
Step (1): Please select communication method:
Serial Connection
Requires a USB Cable (Mini + v2 or above)
Bluetooth Descione - Divetesti interfere - (Mini Lui) en alterna)
Requires a bluetooth interface (Mini+ v2 or above)
Requires a UZBee MACdongle (Mini + v1 only)
Cancel Back Next

Select the COM port number of the Bluetooth connection connected with the brake meter. The COM port number is the same COM port obtained during the Bluetooth pairing process.

Download Wizard		
Step (2): Please make sure your Mini+ is turned ON. Pair your PC with the brake meter via the PC's Bluetooth interface. The bluetooth passkey (PIN) for Mini+ is 0000.		
Step (3): Specify the COM port used by the Bluetooth interface on your computer:		
COM5 -		
Cancel Cancel Next		

Make sure the brake meter is ON. Press Next to continue. Once the connection is established, the datalogger software will acquire a list of all tests currently stored on the device.

Download Wiz	ard		
Test #	Test date	Vehicle reg.	*
▼ 16	19/11/2014 4:38:24 PM		
☑ 17	20/11/2014 11:21:53	Α	
▼ 18	20/11/2014 11:58:03	AJMWT	
V 19	20/11/2014 1:43:56 PM	WM	
V 20	20/11/2014 2:37:46 PM	AM4	
21	20/11/2014 5:36:03 PM		=
22	20/11/2014 5:38:22 PM		-
•	III		•
Select All			
	Cancel	I Back	t 📫 🔓

Select the tests that need to be downloaded and press Next. Datalogger software will then download the selected tests. While downloading, the LCD screen of Mini Plus will display "**Uploading 00%....**"

Download Wizard	
Download Completed.	
AutoStop Mini+S/N:	00123
Number of tests:	22
Cancel	Back Finish

Once the desired tests have been downloaded, press Finish to return to the main window and view test results.

4.5 Using the Data Logger software

The Data logger will display all the saved tests and you can view the results of the particular test and view corresponding graph for each test.



The menu buttons displayed on the top bar can be used to perform the following operations:

- 1. **Open:** Allows opening a previously saved test file on the computer
- 2. Save: Allows the currently downloaded tests to be saved onto a file on the computer

- **3. Export:** This option can be used to view and save the test result in Microsoft Excel compatible format.
- 4. **Print:** this option can be used to print the test result. When printing the tests, the following box will appear. User can select the printer from which the tests should be printed. In order print only a single or a few tests, enter the range of the tests to be printed out. Click on *Print* button to print.

Print	x
Printer Title	
PDFCreator •	. Setup
Options	
Print Range	Print
From: 1 To: 22 Tests	
Include Data table	Cancel

5. **Setting:** this option can be used to view the test results in the units set by the Mini Plus or select a different unit to view the test results.

Settings	×	
◯ Use the same units of measure as Mini+		
Always display tests with the following units:		
Acceleration unit:	g 🔹	
Imperial/Metric:	Metric	
Language:	English	
OK CK	Cancel	

6. About: to view information about Data logger.

5 SPECIFICATION

5.1 Hardware Specifications

Measurement Range: -2.0 to +2.0g with accuracy 2.5% Temperature Range: -10 to $+40^{\circ}$ C

5.2 Features

- Determines tri-axial deceleration, forward as well as sideways deceleration (lane change)
- Calculates and displays SRV36
- Simple 12 button operation via a tactile membrane pad
- Can be installed any where in the vehicle
- Self-aligning by identifying its orientation at the beginning of each test
- Lightweight (< 500grms) and compact (90 x 200 x 35mm)
- LCD display
- Adjustable display control
- Automatic start function
- Automatic shut-off after 15 minutes to preserve battery life (over 24 hours running time)
- Built-in integrity check
- Built-in real time clock
- Calibration is internationally traceable through NATA
- Calibration interval twenty-six months
- 12 months warranty
- Internet support hotline for diagnostics
- Comprehensive after-sales service and assistance
- EIA RS-232c
- Bluetooth interface
- USB interface
- Memory storage: Ninety tests
- PC down load capability and graph
- 16 x 1 character LCD display

6 CALIBRATION PROCEDURE

The Mini Plus must be re-calibrated every two years. The reason for this is to maintain creditability in tests and acceptance of data according to international standards. Each time the unit is turned on; the LCD will show the date that the re-calibration is due. At the time the unit is due for re-calibration, the LCD screen will show: **"Calibration Due! Please contact your vendor for re-calibration"**, and further testing will be disabled. There are two ways of calibrating the Brake Meter - either return the AutoStop Mini Plus to your local distributor or by returning the Brake Meter to Auto Test Products (See Section 6.1).

6.1 Return of AutoStop Mini Plus for Calibration

6.1.1 Packaging

Please remember that you are shipping an electronic instrument. Bubble pack or foam should surround the Mini Plus and should be inserted into a sturdy cardboard box.

6.1.2 Shipping

Labelling - A label noting "Electronic Device - Fragile" should be placed on the box. **Freight Carrier** - Container should be sent "Freight Prepaid". Auto Test Products has no preference on freight carriers. However, we prefer that companies such as TNT, IPEC, UPS, or Federal Express forward units, if a prompt delivery is required.

Ship to: The Service Department, Auto*Test* Products Pty Ltd, 61-63 Parsons St Kensington, VIC, 3031, Australia. Phone: (+61 3) 8840 3004 or to your nearest service distributor.

6.1.3 Documentation

A copy of the purchase order for re-calibration and a packing slip must be included with the shipment. It should note the Purchase Order Number, Date, Serial Number and the address where the unit should be returned.

7 TROUBLESHOOTING

Problem	Potential Cause and Action Necessary
Mini Plus will not turn on	Internal electronics have failed - return unit for
	servicing.
Mini Plus not recording keypad	Keypad damaged- return unit for servicing.
input	
Mini Plus turns itself off during	Battery flat-battery needs to be recharged.
use	
Mini Plus won't run tests	Calibration due - return unit for calibration.
Mini Plus displays Clock failed	The in-built clock has failed. It might be an electronic
	fault, or the unit needs to be recalibrated.
Mini Plus displays Error	The test was not carried out correctly; repeat the test.

8 WARRANTY

AutoTest Products Pty Ltd or any Authorised AutoTest Service Centre warrants this product against defects in material and workmanship for a period of 12 months from the original date of purchase. This warranty applies only to products and components supplied by AutoTest Products which can be identified by the trade name or logo affixed to them or by other documents. AutoTest Products does not warrant any products not supplied by AutoTest Products.

During the warranty period, AutoTest Products or any Authorised Service Centre will repair (or at its option replace) any defective component(s) without charge for parts or labour, provided the product is returned freight prepaid to an authorised AutoTest Service Centre. Transit insurance and return freight will be at the owner's expense.

In order to obtain calibration, warranty or non-warranty service, ship the product, freight and insurance prepaid go to your nearest AutoTest Service Centre. Attach to the product your name, address, contact phone numbers, description of the problem and if a warranty claim, proof of purchase (dated sales receipt or invoice).

AutoTest Products or any Authorised AutoTest Service Centre reserves the right to refuse warranty repair if accident, abuse, misuse or misapplication has damaged the product. In transit or as a result of service or modification by other than an Authorised Service Centre, nor are any other warranties expressed or implied, including any regarding merchantability or fitness for any other particular purpose.

AutoTest Products or any Authorised Service Centre is not responsible for incidental or consequential damages resulting from the breach of any express or implied warranty, including damage to property and, to the extent permitted by law, damages for personal injury.

9 AUTHORISED SERVICE AGENTS:

AUSTRALIA

Autotest Products Pty Ltd

61-63 parsons St, Kensington, Victoria 3031 Australia. Phone: +61 3 88403016.AutoTest Products

CHINA

Itach Autotech Corp Room 703 Building A,Guo Run Commercial Plaza, No.46 West,. Feng Tai District, Beijing 100073 PH: (+_10) 8365 9442

DENMARK

BM Autoteknik A/S Erhvervsparken 7, 9632 Moldrup, PH: (+ 45) 8669 2022

FRANCE

Actia Muller Services Rue Des Tourneballets, Luce, PH: (+332) 3733 3536

FRENCH POLYNESIA

Cogicat snc. 51 Rue Des Remparts Prolongee, B.P 2828, Papeete, TAHITI, 98 713 PH: (+ 6) 8942 8175

HOLLAND

Stertil B.V Stokvis Service, Westkern 3, 9288 CA Kootstertille PH: (+315) 1258 0333

MACEDONIA

Velmar d.o.o. Gjorce Petrov 10, 1000 Skopje, Makedonija. PH: (+389) 2204 0288

MALASIA

Tritech Safety Sdn Bdn No38, 2nd Floor, Jalan Pandan Indah, Kawasan Industri Ampang Tambahan, 68000 Ampang, Selangor D.E. PH: (+603) 4291 0988

NEW ZEALAND

Brake & Transmission NZ 21-27 Omega St., Albany, Auckland PH: (+ 64) 9414 3205

SOUTH AFRICA

Brakecore Supply Co 5 Oosthuise St, Ermelo, 2350. PH: (+271) 7819 3412

UNITED KINGDOM

Tecalemit Garage Equip. Co. Ltd Unit 2,Eagle Road, Langage Bus Pk., Plympton, Plymoth, Devon, PL7 5JY PH: (+017) 5221 9150

UNITED STATES OF AMERICA

Commercial Vehicle Consultants Inc. 144 Overlook Ave, Staten Island, NEW YORK, 10304. PH: (+171) 8980 3651

NOTES:

Copyright 2022 Auto Test Products Pty Ltd ABN 47 005 712 005. [®] denotes a trademark owned by Auto*Test* Products Pty Ltd ABN 47 005 712 005.



AUTOTEST Products Pty Ltd

61-63 Parsons St Kensington VIC 3031 Australia Phone: (+61 3) 8840 3000 Service: (+61 3) 8840 3016 service@autotest.r Sales:(+61 3) 8840 3017

service@autotest.net.au sales@autotest.net.au

www.autotest.net.au